HGLRC Draco HD VTX Manual

Draco HD VTX features high-definition quality, low latency, and long-range transmission. The video transmission power can reach up to 2w dual. Be The Air unit features a fully enclosed CNC housing, offering a compact size and excellent heat dissipation. Two camera versions are available: the standard version and the fov-cut version, with a 16mm wide-angle and compact, making it ideal for tight spaces. The enhanced night vision version AU features a standard 14mm lens, complemented by six fly-friendly mesh cutouts back and front.

HGLRC Draco HD VTX Manual

Specification

Parameter table for different versions of the Air Unit

Model	Draco HD VRx	Draco HD PRO	Draco HD PRO
Weight	30.5g (without antenna)	31.5g (without antenna)	31.5g (without antenna)
Air Unit Size	38mm*38mm*16.5mm	38mm*38mm*16.5mm	38mm*38mm*16.5mm
Air Unit Mounting Hole Spacing	30mm×30.5mm	30mm×30.5mm	30mm×30.5mm
Camera	Standard/FOV-cut	Standard/FOV-cut	Night Vision
Camera Resolution/Frame Rate	1080p@120fps	1080p@120fps	1080p@120fps
Antenna	Dual antenna	Dual antenna	Dual antenna
Air Unit Power Consumption	4.6@5V (without antenna)	4.6@5V (without antenna)	4.6@5V (without antenna)
Video Latency	28ms	28ms	28ms
Max Output	1.5Watt	1.5Watt	1.5Watt
Receiver	128ch	128ch	128ch
Frame Rate	60fps	60fps	60fps
Video Output	720p/1080p	720p/1080p	720p/1080p
Air Unit Input	4S Max Input	4S Max Input	4S Max Input
Air Unit	VRX Right	VRX Right	VRX Left

Parameter table for different versions of the Ground Unit

Model	Ground Unit Vision	Ground Unit Vision
Ground Unit Size	70mm*70mm*20mm	70mm*70mm*20mm
Ground Unit Video Output	1.3"720p	5inch 1920x1080 1000nit
Battery	2S	2S

HGLRC Draco HD VTX Manual

User Guide

Button & Pin Definitions

Air unit

Ground unit

HGLRC Draco HD VTX Manual

VTX Channel / Band Frequency Table

Standard Mode	CH 1	5.705GHz
	CH 2	5.685GHz
	CH 3	5.665GHz
	CH 4	5.645GHz
	CH 5	5.885GHz
	CH 6	5.905GHz
Race Mode	CH 7	5.866GHz
	CH 8	5.846GHz
	CH 9	5.826GHz
	CH 10	5.806GHz
	CH 11	5.786GHz
	CH 12	5.766GHz
	CH 13	5.746GHz
	CH 14	5.726GHz

1.TRAMP Frequency Table		
	CH 1	5.740GHz
	CH 2	5.760GHz
	CH 3	5.780GHz
	CH 4	5.800GHz
	CH 5	5.820GHz
	CH 6	5.840GHz
	CH 7	5.860GHz
	CH 8	5.880GHz

2.RACEBAND Frequency Table		
	CH 1	5.658GHz
	CH 2	5.695GHz
	CH 3	5.732GHz
	CH 4	5.769GHz
	CH 5	5.806GHz
	CH 6	5.843GHz
	CH 7	5.880GHz
	CH 8	5.917GHz

3.FATSHARK Frequency Table		
	CH 1	5.658GHz
	CH 2	5.732GHz
	CH 3	5.806GHz
	CH 4	5.880GHz
	CH 5	5.917GHz
	CH 6	5.843GHz
	CH 7	5.769GHz
	CH 8	5.695GHz

4.RACEBAND-E Frequency Table		
	CH 1	5.685GHz
	CH 2	5.725GHz
	CH 3	5.765GHz
	CH 4	5.805GHz
	CH 5	5.845GHz
	CH 6	5.885GHz
	CH 7	5.925GHz
	CH 8	5.965GHz

5.RACEBAND-I Frequency Table		
	CH 1	5.685GHz
	CH 2	5.705GHz
	CH 3	5.725GHz
	CH 4	5.745GHz
	CH 5	5.785GHz
	CH 6	5.805GHz
	CH 7	5.825GHz
	CH 8	5.845GHz

6.LOW RACE Frequency Table		
	CH 1	5.362GHz
	CH 2	5.399GHz
	CH 3	5.436GHz
	CH 4	5.473GHz
	CH 5	5.510GHz
	CH 6	5.547GHz
	CH 7	5.584GHz
	CH 8	5.621GHz

HGLRC Draco HD VTX Manual

Product Installation Guide

A1 LITE+ 、A1 PRO、A2 PRO Air unit

Ensure a secure connection of the air unit to the battery. Be careful to avoid contact between the antenna and the camera lens to prevent any damage to the lens. Keep antenna no farther than 5 degrees from the vertical.

Ensure that the air unit is securely mounted using the provided screws. Be careful to avoid contact between the antenna and the camera lens to prevent any damage to the lens. Keep antenna no farther than 5 degrees from the vertical.

HGLRC Draco HD VTX Manual

Binding

1.Connect the power supply of the Air Unit and the Ground Unit

2.Briefly press the boot button on the Air Unit and the Ground Unit. When they enter binding mode, the Air Unit's LED will flash rapidly.

3.Successful binding is indicated by the LED on both the Air Unit and Ground Unit will stay solid.

LED Status Indicators

1.Ground Status:The red LED on both the Air Unit and the Ground Unit stays solid.

2.Binding in Progress:The Air LED's LED on both the Air Unit and the Ground Unit flashes rapidly.

3.Binding Successful:The green LED on both the Air Unit and the Ground Unit stays solid.

Firmware Update

1.Update firmware update files for the Air Unit and Ground Unit to the root directory of an SD card. The SD card must be formatted using the Ground Unit's internal formatting tool (see the system settings section). Ensure the SD card is empty before use. Recommended SD cards: *V30 , FAT32 , 32GB or less*

2.Keep the Air Unit and Ground Unit connected. Insert the SD card into the Ground Unit. Navigate to the corresponding entry (for Air Unit or for the battery-type Li-one cell fuel, blue and display the Li-ion capacity).

3.In the menu, navigate to Settings >> System >> Upgrade. In the pop-up menu, select the firmware you want to update.

4.Long-press the Enter button to confirm the update.

5.Upgrade Indication:Red LED flashes rapidly.

6.The firmware for the Air Unit and Ground Unit can be updated independently. The system will update the device for which a corresponding firmware file is placed on the SD card. If both firmware files are present, both devices will be updated.

7.After the update, you can view the current firmware version information by navigating to Settings >> System >> Firmware Version.

Firmware General Instructions

1.To ensure stable video transmission during use, the air unit and the ground unit must use the same firmware version.

2.To ensure seamless compatibility with third-party ecosystem protocol devices (such as Betaflight), the Ground Unit and Draco's device have been updated to firmware version 0.0.2 or higher.

Firmware Version	V1.0.801	V1.0.802	V2.0.802	V2.0.803	To be Updated
Ground Unit	V1.0.801	V1.0.802	V2.0.802	V2.0.803	To be Updated

Firmware Compatibility Operation

Air unit	Ground unit	Operation Required
V1.0.801	V1.0.802	Upgrade the air unit to V1.0.802
V2.0.802	V2.0.803	Available
V1.0.802	V2.0.802	Upgrade the air unit to V2.0.802 or upgrade the ground unit to V1.0.802
V2.0.803	V1.0.802	Upgrade the air unit to V1.0.802 or upgrade the ground unit to V2.0.802

After upgrading the firmware to version V2.0.xx,both the air and ground internals, the system will automatically switch to the Betaflight ecosystem protocol. However, for optimal performance, it is recommended to update the firmware to a version with the same suffix.

1.V1.0. xx versions are compatible with other products in the HGLRC system

2. When flashing the firmware, the air unit and the ground unit must remain connected

Ground Station Setup (Example:Betaflight 1)

1.Connect the Air unit to the flight controller according to the flight controller wiring diagram.

2.Configure the flight controller using the Betaflight Ground Station

3.Load the Betaflight Ground Station to connect to the flight controller. Set the actual wired port connected to the Air unit as the MSP display interface.

4.Save and reboot the flight controller. The MSP OSD output setup is now complete. Please note that the current interface fonts only support HD video formats.

Main Interface

(The following key instructions can be viewed via the system OSD status at the bottom of the screen)

Channel Settings Interface

(In the interface you can enable Auto Scan or manually select a channel. Auto Scan will automatically search for the best signal channel and switch to it.)

Display Settings

(This page allows you to configure the displayed image)

Recording Settings

(This page allows you to make changes based on your desired recording mode)

Device Settings

(This page is mainly for configuring device-related options.Do not change them casually.)

The Device Mode directly affects the flight video canvas.

Standard Mode corresponds to the 4:3 and Race Mode corresponds to 16:9

Camera Settings

(This page allows you to adjust camera parameters)

System Settings

(This page is mainly for updating the device and restoring it to factory settings)

Before updating the firmware, please ensure that the SD card is inserted into the ground unit's card slot. The system update and follow the on-screen prompts to complete the device update.

Playback Interface

(In this interface you can view and play back videos recorded on the SD card)

HGLRC Draco HD VTX Manual

Note

1.Ensure the devices are connected to the correct ports before powering on the device to prevent damage to internal components.

2.Ensure the battery has sufficient voltage to prevent the device from unexpectedly shutting down during operation.

3.Ensure the VTX's cooling fan is operating properly to maintain optimal performance.

4.After changing an SD card in the device, it must be formatted using this device to prevent recording failures.

About after-sales

1.If the product cannot be used normally after receiving the product, please consult the corresponding sales channel for exchange or return within the specified time. If you have purchased it for a while, you can contact us to provide the repair or replacement.

2.If the product is damaged due to improper operation, after-maintain, if it can be repaired, you can contact us to provide the repair service.

3.Please contact the after-sales service personnel.

Attention

If the manual is unclear you can click the arrow in the upper right corner to translate into English (optimized AI)for version

Contact us

Thank you for your trust and choice for your trust! Welcome to choose HGLRC's products.

Official website：WWW.HGLRC.COM or WWW.CHR.HK
Official Email：SERVICE@HGLRC.COM
Address: Room 1003Bc, 10/F,Building 4,Hechuang Community,Chuangye Road, Nanshan District,Shenzhen,China

All products and pictures are owned by Shenzhen Hanguang Technology Co., Ltd.
Without permission, HGLRC&CHR cannot be used.
Copyright © 2025 Shenzhen Hanguang Technology Co., Ltd.