Neck strap for RC

Neck strap for an RC transmitter
User manual



Read this manual before first use and keep it for future reference.

Rotorama, s.r.o. · www.rotorama.com

Contents

1. Product description

1.1 What it is for

1.2 Technical data and package contents

2. Use

2.1 Parts

2.2 Adjusting the length

2.3 Attaching and detaching the transmitter

2.4 Safety and care

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

3.2 Disposal

4. Warranty and rights arising from defective performance

1. Product description

1.1 What it is for

The **Rotorama Neck strap for RC** is a strap for hanging an RC transmitter around your neck. The transmitter hangs in front of the pilot, so your hands do not have to carry its weight and can concentrate fully on the sticks – especially useful during longer flying sessions or with a heavier transmitter.

The part around the neck has comfortable padding, so the strap does not press or cut into your neck. The strap length is adjusted with two slide buckles. The strap is attached to the transmitter with a carabiner; thanks to the quick-release buckle, you can easily detach it from the transmitter without opening the carabiner.



Rotorama Neck strap for RC

1.2 Technical data and package contents

Product designation	Rotorama Neck strap for RC
Intended use	hanging an RC transmitter around the neck
Strap length	50–65 cm (adjustable)
Width	20–31 mm
Length adjustment	two slide buckles
Attachment to transmitter	carabiner and quick-release buckle
Padding	yes, in the neck section
Package contents	1× strap
Not included	RC transmitter

2. Use

2.1 Parts



Strap end with buckles and detachable end piece with carabiner

① **Slide buckles** – adjust the strap length.

② **Quick-release buckle – male part** at the end of the strap.

③ **Carabiner** – clips onto the strap attachment point of the transmitter.

④ **Quick-release buckle – female part** on the detachable end piece with the carabiner.

2.2 Adjusting the length

① Put the strap over your head so that the padding rests on the back of your neck.

② Attach the transmitter (Chapter 2.3) and check the height at which it hangs. The transmitter should hang so that you can hold it in a comfortable position with slightly bent elbows, without having to lift it or bend down to it.

③ Adjust the length by moving the slide buckles ① along the strap. Each buckle adjusts one side of the strap.

④ Set both sides to approximately the same length so that the padding stays centred behind your neck.

2.3 Attaching and detaching the transmitter

▶ Attaching

① Press the lever of the carabiner ③ and hook the carabiner into the strap attachment point of the transmitter. The location of the attachment point is

given in the transmitter's manual.

② Check that the carabiner lever has closed by itself after release.

③ Push the male part ② into the female part ④ until both side latches click into place.

④ Pull lightly to check that the buckle is firmly connected.

▶ Detaching

Press both side latches of the male part ② and pull it out of the female part ④. The carabiner with the female part can stay on the transmitter – next time you simply click the strap back in.

❊ A transmitter without a strap attachment point cannot be carried with this strap.

2.4 Safety and care

- The strap is intended only for carrying an RC transmitter. Do not use it to hang other objects, to secure persons or to lift loads.
- Before each use, check that the strap is not torn or frayed and that the buckles and the carabiner are not cracked or otherwise damaged. Do not use a damaged strap.
- If the strap or the transmitter gets caught on an obstacle, open the quick-release buckle.
- When handling a drone with a connected battery, make sure that neither the loose end of the strap nor the hanging transmitter gets near the propellers.
- The strap is worn around the neck – keep it out of the reach of small children; risk of strangulation.
- Wipe a dirty strap with a damp cloth. Store it in a dry place away from direct sunlight.

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorama.cz
Phone	+420 252 252 098
Website	www.rotorama.com

3.2 Disposal

- The product contains no electrical or electronic components and no batteries; take-back of electrical equipment therefore does not apply to it.
- Dispose of a worn-out strap with mixed municipal waste or take it to a waste collection site in accordance with the rules of your municipality.
- Sort the packaging by material type into the appropriate separate waste containers.
- If you use the product outside the Czech Republic, follow the waste management regulations of the country in which you use it.

4. Warranty and rights arising from defective performance

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.