Ethix SD Card Holder

Holder for 10 microSD memory cards
User Manual



The holder is intended for microSD cards only. Memory cards are not included.

www.rotorama.com

Contents

1. Product description

1.1 Intended use

1.2 Specifications and package contents

2. Use

2.1 Inserting a card

2.2 Removing a card

2.3 Care and safety

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

3.2 Disposal

4. Warranty and rights arising from defective performance

1. Product description

1.1 Intended use

The **Ethix SD Card Holder** is a credit-card-sized case for keeping up to **10 microSD memory cards** neatly organised. It is ideal for FPV pilots who swap cards between action cameras, DVR recorders and FPV goggles and do not want them rattling around loose in a backpack, where they are easily lost.

The cards slide into **numbered slots 1–10** around the edge of the holder, so you can easily tell which card belongs to which flight or camera. A semicircular cut-out at each slot makes it easy to push the card out with your thumb, and the transparent top layer keeps the card labels visible. Being the size of a credit card, it fits in a wallet, a backpack pocket or a goggle case.



Ethix SD Card Holder with microSD cards inserted (cards not included)

1.2 Specifications and package contents

Product designation	Ethix SD Card Holder
Brand	Ethix
Product type	Holder (case) for microSD memory cards
Capacity	10 microSD cards (slots numbered 1–10)
Size	Credit card format
Material	Plastic (transparent frame, printed insert)
Package contents	1× microSD card holder
Not included	microSD memory cards

※ The holder is intended for microSD cards only. Full-size SD cards will not fit.

2. Use

2.1 Inserting a card

① Before removing a card from a camera, recorder or goggles, switch the device off so that a recording being written is not damaged.

② Choose a free slot. You can note the slot number, e.g. which flight or camera the card belongs to.

③ Carefully slide the microSD card into the slot without force until it is fully inside the holder. The card label remains visible through the transparent top layer.

2.2 Removing a card

① Place your thumb in the semicircular cut-out of the respective slot.

② Push the card out of the slot with light pressure and grip it by its edge.

③ Insert the card back into the device; avoid touching the card contacts with your fingers where possible.

2.3 Care and safety

- Do not force cards into the slots and do not bend the holder – the plastic could crack.
- Do not leave the holder in direct sunlight, in a hot car or near sources of heat.
- Do not clean it with solvents or aggressive cleaning agents; a dry or slightly damp cloth is sufficient.
- microSD memory cards are small objects that can be swallowed. Keep the holder with cards out of the reach of small children.

3. Information for the EU and Czech Market

The information in this chapter describes the situation in the Czech Republic. If you use the product in another country, the law of the country in which the product is used shall prevail.

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorama.cz
Phone	+420 252 252 098
Website	www.rotorama.com

3.2 Disposal

- The product contains no electronic components or batteries and is not electrical equipment.
- At the end of its service life, dispose of it with sorted waste in accordance with your local rules (plastics) or take it to a collection yard.
- Sort the product packaging according to its material.
- Remove all memory cards from the holder before disposal.

4. Warranty and rights arising from defective performance

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.