Tool bag

Readytosky · tool bag
User Manual



Please read this manual before first use and keep it for future reference.

www.rotorama.com

Contents

1. Product description

1.1 Intended use

1.2 Specifications and package contents

2. Use

2.1 Storing your tools

2.2 Safe storage rules

2.3 Care and storage

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

3.2 Disposal

4. Warranty and rights arising from defective performance

1. Product description

1.1 Intended use

The Readytosky Tool bag is a zippered fabric pouch that keeps your tools and small accessories together – in your backpack, in your field bag or on your workbench. No more hunting for screwdrivers, wrenches and spare screws all over your backpack.

Inside the pouch there are **two mesh pockets** and a **removable hook-and-loop divider** that lets you split the space according to what you carry. A handle on the side of the pouch is used for carrying.



Readytosky Tool bag (closed)

1.2 Specifications and package contents

Manufacturer	Readytosky
Product designation	Readytosky Tool bag
Type	fabric tool pouch
Closure	zipper
Interior layout	2 mesh pockets, removable hook-and-loop divider
Package contents	1× Tool bag
Not included	tools or any other equipment

※ The manufacturer does not specify dimensions, weight or material.

2. Use

2.1 Storing your tools

① Unzip the pouch and open it.

② Position the hook-and-loop divider to split the space as needed, or remove it completely if you want to store a larger item.

③ Put small parts – screws, nuts, spare prop nuts, cable ties – into the mesh pockets. You can see what is inside without taking it out.

④ Place your tools in the main compartment so that the pouch closes without force.

⑤ Close the zipper. Carry the pouch by the side handle or put it in your backpack.

2.2 Safe storage rules

- Store sharp tools (knives, scalpels, awls) with their blades covered so that they do not damage the fabric or injure you when taking them out.
- Do not put in a hot soldering iron, soldering tip or any other hot object – let it cool down completely first.
- The pouch **is not a Li-Po battery safety bag**. Do not charge batteries in it and do not carry them loose next to metal tools – there is a risk of short circuit.
- Do not overfill the pouch; an overstrained zipper is easily damaged.
- Keep the pouch and the small parts in it out of the reach of small children.

2.3 Care and storage

- Remove dirt and dust with a vacuum cleaner or wipe with a damp cloth. The manufacturer does not provide washing instructions.
- Let the pouch and its contents dry before closing and storing it.
- Store in a dry place, away from direct sunlight and heat sources.
- Keep the zipper and the hook-and-loop fastener free of sand and dirt so that they work reliably.

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorama.cz
Phone	+420 252 252 098
Website	www.rotorama.com

3.2 Disposal

The pouch contains no electronics or batteries and is not covered by the take-back scheme for electrical equipment. At the end of its service life, dispose of it via separate waste collection or at a municipal collection site in accordance with your local rules; sort the packaging by material type.

Waste management rules differ from country to country. The information in this manual describes the situation in the Czech Republic. If you use the product in another country, follow the regulations of the country in which you use it.

4. Warranty and rights arising from defective performance

4.1 Buyer's rights under Czech law

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.