Battery Strap

Rubberized Kevlar 20x250
User Manual



Before every flight, check that the strap is not damaged and that the battery is held firmly on the frame.

Rotorama, s.r.o. · www.rotorama.com

Contents

1. Product description

1.1 What it is for

1.2 Technical data and package contents

2. Use

2.1 Mounting the battery

2.2 Inspection, care and safety

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

3.2 Disposal

4. Warranty and rights arising from defective performance

1. Product description

1.1 What it is for

Rotorama Battery Strap – Rubberized Kevlar 20x250 is a Kevlar strap for securing a battery to the frame of an FPV drone or model. Thanks to the material used and the metal buckle, the strap is very durable; the metal buckle is made in one piece, without a weld.

The strap is stitched with rubber, so it does not slip on the battery and holds it firmly. The Rotorama logo on the strap is coloured and embroidered.



Rotorama Battery Strap – Rubberized Kevlar 20x250

1.2 Technical data and package contents

Product designation	Rotorama Battery Strap – Rubberized Kevlar 20x250
Material	Kevlar with rubber
Buckle	metal, one piece without a weld
Dimensions	20 × 250 mm
Weight	7.6 g
Package contents	1× strap
Not included	battery, frame, anti-slip battery pad

2. Use

2.1 Mounting the battery

The strap wraps around the battery and part of the frame and pulls them together. Before mounting for the first time, check that the strap is long enough to go around the battery and frame and that enough strap remains to fold back and fasten.

① Thread the strap through the holes or slots in the frame intended for it, or lead it around the frame plate.

② Place the battery on the frame in the desired position.

③ Pass the free end of the strap through the metal buckle and pull the strap tight.

④ Fold the end of the strap back and fasten it – press it down along the entire length where the strap overlaps.

⑤ Check that the battery cannot be moved or rotated. If it can, loosen the strap, pull it tight again and fasten it.

To remove the battery, unfasten the end of the strap, loosen it in the buckle and slide the battery out. The strap can stay threaded in the frame.

2.2 Inspection, care and safety

- **Before every flight**, check that the strap is not torn or frayed, that the fastening holds and that the buckle is not deformed. Replace a damaged strap.
- A loose battery may fall out during flight or hit the propellers. Therefore always pull the strap tight and fasten it.
- The free end of the strap must not reach into the path of the propellers or into moving parts of the model.
- Do not pull the strap forcefully over sharp edges of the frame – they may chafe through it. Do not overtighten a Li-Po battery; its casing may be damaged.
- Keep the fastening clean – grass, sand and dust reduce its grip.
- The strap is a modelling accessory. Do not use it for hanging, lifting or securing persons or loads.
- When operating a drone or model, follow the regulations of the country in which you operate it – the law of that country prevails.
- Keep out of the reach of small children.

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorama.cz
Phone	+420 252 252 098
Website	www.rotorama.com

3.2 Disposal

- The product **is not electrical equipment** and contains no battery or accumulator. Take-back of electrical equipment does not apply to it.
- Dispose of a worn strap with mixed municipal waste. You can separate the metal buckle and hand it over for metal collection.
- Sort the product packaging according to the type of material.
- Follow the waste management rules applicable in the municipality and country in which you dispose of the product.

4. Warranty and rights arising from defective performance

Rights of the buyer under Czech law

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.