Goggles 2 Pouch

ETHIX — FPV goggle pouch
User manual



Read this manual before first use and keep it for future reference.

www.rotorama.com

Contents

1. Product description

1.1 Purpose

1.2 Specifications and package contents

2. Use

2.1 Storing the goggles in the pouch

2.2 Safety, care and storage

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

3.2 Disposal

4. Warranty and rights arising from defective performance

1. Product description

1.1 Purpose

ETHIX Goggles 2 Pouch is a soft pouch for carrying and storing FPV goggles. According to the manufacturer and the retailer, it is intended for analog FPV goggles as well as for digital goggles such as DJI Goggles 2 or Walksnail Avatar. It is large enough to hold HD goggles with the antennas attached.

The outer part of the pouch is made of robust nylon and the inside is lined with soft fleece, which protects the goggles from scratches and damage while travelling. The pouch closes with a drawstring and has an exterior pocket for small accessories such as cables or antennas.



Pouch with FPV goggles stored inside

1.2 Specifications and package contents

Product designation	ETHIX Goggles 2 Pouch
Manufacturer	ETHIX (Team BlackSheep)
Dimensions	250 × 65 × 110 mm
Material	nylon exterior, fleece lining
Closure	drawstring with self-cinching pull tabs
Pocket	exterior side pocket for accessories

Package contents

- 1× FPV goggle pouch
- 1× microfiber bag

NOT included in the package

- FPV goggles, antennas, cables, battery or any other accessories shown in the photos.

2. Use

2.1 Storing the goggles in the pouch

① Switch the goggles off and disconnect the power cable and battery. If the goggles have been in use, let them cool down before storing them.

② Clean the lenses and display or cover them with the supplied microfiber bag so that they do not get scratched during transport.

③ Loosen the drawstring, open the pouch and insert the goggles. The antennas can stay attached – make sure they are not bent or pinched.

④ Pull the drawstring tabs to close the pouch until the opening is shut.

⑤ Put small accessories (cables, spare antennas) into the exterior pocket and close the pocket with its flap.

2.2 Safety, care and storage

- The pouch protects the goggles from scratches and normal wear during transport. It is not designed to protect against drops from height, strong impacts or crushing – do not place heavy objects on it.
- The manufacturer does not state any water resistance. Protect the pouch and the goggles from rain and moisture; let a damp pouch dry before storing the goggles in it.
- Do not store Li-Po or Li-ion batteries in the pouch while they are connected to the goggles. Do not use the pouch to store or charge batteries.
- Do not leave the pouch with the goggles in direct sunlight or in a hot car, and do not place it near fire or other heat sources.
- Shake dirt out of the pouch and wipe the outside with a damp cloth. The manufacturer does not provide washing instructions.
- The drawstring pouch and the bag are not toys – keep them out of reach of small children.



Fleece inner lining (left) and exterior pocket with flap (right)

3. Information for the EU and Czech Market

The information in this chapter describes the situation in the Czech Republic. If you use the product in another country, follow the regulations of the country in which you use it.

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorama.cz
Phone	+420 252 252 098
Website	www.rotorama.com

3.2 Disposal

- The product is not electrical equipment, contains no batteries or accumulators and is not subject to the take-back of electrical equipment.
- At the end of its service life, hand the pouch over to a textile collection or dispose of it in accordance with the waste management rules of your municipality.
- Sort the product packaging into the appropriate container for separated waste according to the type of material.

4. Warranty and rights arising from defective performance

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.