



TBS Ummagrip

Anti-slip battery pad
Ummagrip Battery Pad – TBS Edition



Read this manual before use and keep it for future reference.

www.rotorاما.com

Contents

1. Product description

1.1 What it is for

1.2 Specifications and package contents

2. Use

2.1 Attaching to the frame

2.2 Securing the battery

2.3 Cleaning and care

3. Information for the EU and Czech market

3.1 Importer and responsible person in the EU

3.2 Disposal

4. Warranty and rights in case of defects

1. Product description

1.1 What it is for

Ummagrip is a very sticky pad that is attached to the drone frame underneath the battery. Its purpose is to hold the battery firmly in place so that it does not slide out or get ejected from the frame in a crash or impact, and at the same time to protect it from direct contact with the frame and bolt heads.

On the frame side the pad has a permanent 3M adhesive; on the battery side it has a textured relief pattern that grips the battery without sticking to it. The pad is universal – it can be cut to size and fitted to most frames. Always secure the battery with a strap (lipo strap) as well; the pad does not replace the strap, it complements it.



TBS Ummagrip in its original packaging

1.2 Specifications and package contents

Product designation	Ummagrip Battery Pad – TBS Edition
Manufacturer	Team BlackSheep (TBS)
Dimensions	100 × 50 × 3 mm (L × W × T)
Adhesive layer	permanent 3M adhesive (frame side)
Surface	textured relief pattern (battery side)
Package contents	1 × Ummagrip pad
Not included	battery, battery strap (lipo strap), frame

2. Use

2.1 Attaching to the frame

- ① Check where the battery will sit on the frame and, if necessary, cut the pad to size with sharp scissors or a knife. Thanks to its 3 mm thickness, the pad also covers the bolt heads on the top plate of the frame.
- ② Clean the frame surface of dust, dirt and grease and let it dry completely. The adhesive only holds reliably on a clean, dry surface.
- ③ Peel the protective liner off the adhesive and place the pad on the frame. Do not touch the adhesive layer with your fingers.
- ④ Press the pad firmly over its entire surface. The adhesive is permanent – repositioning or re-applying is not intended, so place the pad accurately the first time.

❖ **Make sure the pad does not cover the slots or openings for the battery strap.**

2.2 Securing the battery

- Place the battery on the pad and **always secure it with a high-quality strap** (lipo strap). Only the combination of the sticky pad and the strap effectively prevents the battery from being ejected in a crash.
- Tighten the strap so that the battery cannot be moved on the pad by hand.
- Before every flight, check that the pad adheres to the frame over its entire surface and that the battery is firmly seated.

2.3 Cleaning and care

Over time the pad picks up dust and dirt and its grip decreases. The best way to clean it is with a **damp sponge** – plain water is all that is needed to loosen dust and dirt. As the pad gets cleaner and drier, it becomes stickier again.

- Do not use paper towels, tissues, T-shirts or rags – they may leave lint on the surface.
- The pad does not need to be perfectly clean to work – it still holds the battery even when slightly dusty.

3. Information for the EU and Czech market

The information in Chapters 3 and 4 describes the situation under the law of the Czech Republic. If you use the product in another country, the law of the country in which you use it is decisive.

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorاما.cz
Phone	+420 252 252 098
Website	www.rotorاما.com

3.2 Disposal

- The pad is not electrical equipment and contains no batteries. At the end of its service life, dispose of it with mixed household waste unless local regulations specify otherwise.
- Sort the packaging by material type into the appropriate collection container.

4. Warranty and rights in case of defects

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.