Battery Strap 16x150

Strap for securing the flight battery
User manual



Read this manual before use and keep it for future reference.

Rotorama, s.r.o. · www.rotorama.com

Contents

1. Product description

1.1 What it is for

1.2 Technical data and package contents

2. Use

2.1 Parts

2.2 Securing the battery

2.3 Inspection, maintenance and storage

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

3.2 Disposal

4. Warranty and rights arising from defective performance

4.1 Rights of the buyer under Czech law

1. Product description

1.1 What it is for

Rotorama Battery Strap 16x150 is a strap with the Rotorama logo for securing the Li-Po flight battery to the frame of an FPV drone (quadcopter). It is tightened using a plastic buckle and fastened with hook-and-loop (Velcro).

The length of 15 cm is suitable for securing smaller batteries on 3" quadcopters, through either the top or the bottom plate of the frame. A properly tightened strap holds the battery in place throughout the flight.



Rotorama Battery Strap 16x150

1.2 Technical data and package contents

Product designation	Rotorama Battery Strap 16x150
Brand	Rotorama
Strap width	16 mm
Strap length	150 mm (15 cm)
Fastening	plastic buckle and hook-and-loop
Intended use	smaller flight batteries on 3" quadcopters, mounted through the top or bottom plate of the frame
Package contents	1× battery strap
Not included	battery, drone or frame, anti-slip battery pad

2. Use

2.1 Parts



Parts of the strap

① **Plastic buckle** – the loop through which the free end of the strap is threaded and against which the strap is tightened.

② **Hook-and-loop** – when the free end is folded back, both layers of the strap join and hold the strap tight.

③ **Free end of the strap** – is threaded through the drone frame and the buckle.

2.2 Securing the battery

① Thread the free end of the strap ③ through the strap slots in the frame plate – through the top or the bottom plate, depending on the frame design.

② Place the battery on the frame plate in the required position and wrap the strap around it.

③ Thread the free end through the buckle ① and fold it back.

④ Pull the strap tight and press the hook-and-loop ② together along the whole overlap.

⑤ Check that the battery cannot slide or twist.

※ The strap must not reach into the propeller paths, and the battery lead or connector must not be pinched under the strap.

- Tighten the strap firmly, but do not use excessive force – the Li-Po battery must not be deformed.
- Do not route the strap over sharp edges of the frame that could cut it.

- For better grip, an anti-slip pad can be placed between the battery and the frame (not included).

2.3 Inspection, maintenance and storage

- Before every flight, check that the strap is properly tightened and the hook-and-loop holds along its whole length.
- After a crash, inspect the strap and the buckle. Replace a torn, cut or frayed strap, a cracked buckle or hook-and-loop that no longer holds reliably immediately – a loose battery can fall out during flight.
- Regularly remove grass, dust and dirt from the hook-and-loop, as they reduce its grip.
- Store the strap in a dry place, away from direct sunlight and heat sources.

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorama.cz
Phone	+420 252 252 098
Website	www.rotorama.com

3.2 Disposal

- The product is not electrical equipment and does not contain a battery; take-back of electrical equipment does not apply to it.
- Dispose of a worn strap according to the waste sorting rules where you live – where local rules allow, the plastic buckle can be separated and put into sorted plastic waste, the rest into mixed municipal waste.
- Hand the packaging over for recycling according to the type of material.

4. Warranty and rights arising from defective performance

4.1 Rights of the buyer under Czech law

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.