Ethix Prop Organizer

Propeller organizer
User manual



Read this manual before first use and keep it for future reference.

www.rotorama.com

Contents

1. Product description

1.1 What it is for

1.2 Technical data and package contents

2. Use

2.1 Storing propellers

2.2 Safety and care

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

3.2 Disposal

4. Warranty and rights arising from defective performance

1. Product description

1.1 What it is for

The **Ethix Prop Organizer** is a set of three transparent zip pouches stitched together along one side like a book. It is used to store and carry propellers for FPV drones in a clear and organised way, so you no longer have to carry them loose or in many individual bags.

Each pouch has its own purpose: the **green** one is intended for clockwise propellers (CW), the **clear** one for counter-clockwise propellers (CCW) and the **smoked grey** one for bent, chipped or otherwise damaged propellers. At the flying field you will always reach for a propeller with the correct direction of rotation.



Pouch for clockwise propellers (CW) with propellers stored inside

1.2 Technical data and package contents

Product designation	Ethix Prop Organizer
Brand	ETHIX
Number of pouches (pockets)	3, each closable with a zip
Pouch colours	green (CW), clear (CCW), smoked grey (damaged propellers)
Dimensions	16 × 24 cm
Weight	90 g
Package contents	1× Prop Organizer (set of three stitched pouches)
Not included	propellers (shown in the photos for illustration only)

2. Use

2.1 Storing propellers

① Open the zip of the pouch in which you want to store the propellers. The pouches are stitched together and open like the pages of a book.

② Put clockwise propellers (CW) into the **green** pouch marked “CW”.

③ Put counter-clockwise propellers (CCW) into the **clear** pouch marked “CCW”.

④ Put bent, chipped or otherwise damaged propellers into the **smoked grey** pouch. This keeps them away from the propellers that are ready to fly.

⑤ Close the zip of the pouch completely so that the propellers do not fall out while being carried.



Clear pouch marked “CCW” for counter-clockwise propellers

❉ The direction of rotation is indicated by the marking on the propeller (e.g. CW / CCW). Always check a propeller again before mounting it on the motor – the correct direction of rotation is essential for a safe flight.



Smoked grey pouch for damaged propellers

2.2 Safety and care

- Do not mount damaged propellers from the smoked grey pouch on a drone again – they may break during flight.
- Do not overfill the pouches. An overfilled pouch strains the zip, and the sharp edges of the propellers may damage the film.
- Keep out of reach of small children. The plastic pouches are not a toy and propellers have sharp edges.
- Do not leave the organizer in direct sunlight or near a heat source for a long time (e.g. behind a car window in summer) – the film could deform.
- Wipe dirty pouches with a damp cloth and let them dry before further use. Do not use solvents.

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorama.cz
Phone	+420 252 252 098
Website	www.rotorama.com

3.2 Disposal

- The product contains no electronics or batteries and is not subject to the take-back of electrical equipment.
- At the end of its service life, dispose of it in sorted waste according to the rules of your municipality, or take it to a collection yard. Sort the product packaging according to its material.
- The waste management regulations of the country in which you use the product are decisive; the instructions above describe the usual procedure in the Czech Republic.
- Proper disposal helps prevent negative impacts on the environment and contributes to the reuse of secondary raw materials.

4. Warranty and rights arising from defective performance

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.