TBS Gear Pouch V2

Padded pouch for FPV gear
User Manual



Read this manual before first use and keep it for future reference.

Rotorama, s.r.o. · www.rotorama.com

Contents

1. Product description

1.1 What it is for

1.2 Specifications and package contents

2. Use

2.1 Arranging the interior

2.2 Storing your gear

2.3 Care and storage

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

3.2 Disposal

4. Warranty and rights arising from defective performance

1. Product description

1.1 What it is for

The **TBS Gear Pouch V2** is a padded fabric pouch made by Team BlackSheep (TBS) for carrying and storing FPV gear. According to the manufacturer, it comfortably holds a TBS Tango 2 radio and Fatshark-size FPV goggles. The walls and the dividers are padded to protect your gear.

The pouch has two separate compartments. One holds bulkier gear (radio, goggles) and is organised with repositionable padded dividers. The other compartment has an elastic retention system and small pockets for cables, tools, soldering accessories, antennas and similar small items.



The pouch with both compartments open. The radio, goggles and tools shown are not included.

1.2 Specifications and package contents

Product designation	TBS Gear Pouch V2
Manufacturer	Team BlackSheep (TBS)
Dimensions	280 × 80 × 210 mm
Weight	260 g
Material – exterior	nylon
Material – interior	padded, Velcro-receptive fabric
Number of compartments	2
Package contents	1× TBS Gear Pouch V2 2× long padded divider 1× short padded divider

※ The pouch is supplied empty. The radio, FPV goggles, tools, cables and any other gear shown in the photos are not included.

2. Use

2.1 Arranging the interior

The inner walls of the compartment for bulkier gear are made of Velcro-receptive fabric. You can therefore reposition the padded dividers freely and split the space to suit the shape and size of your gear.

① Unzip the compartment and remove any dividers you do not need.

② Put in the gear you want to carry and find the best arrangement.

③ Press the dividers onto the walls with their Velcro so that they hold the gear in place and it cannot slide around inside the pouch.

④ Close the zip and check that the gear does not move when you tilt the pouch.



Compartment with dividers – example with a radio and goggles (not included).

2.2 Storing your gear

Put small items – cables, tools, soldering accessories, spare antennas – in the second compartment. Secure them with the elastic loops or place them in the small pockets so that they do not fall out or rub against other gear while being carried.



Compartment with elastic loops and pockets – example with tools (not included).

▶ **Safe storage guidelines**

- Switch off electronics and disconnect their batteries before packing them.
- The pouch **is not a fireproof bag for Li-Po batteries**. Carry and store Li-Po batteries in a bag designed for that purpose.
- Store sharp tools (knives, cutters, tweezers) so that their tips and blades cannot damage your gear or pierce the fabric.
- Unscrew or fold down antennas that protrude from your gear so that they do not break when the zip is closed.
- Do not overfill the pouch – the zip could be damaged and the padding would protect your gear less effectively.

2.3 Care and storage

- Remove dust and dirt with a brush or a damp cloth. The manufacturer gives no washing instructions, so we do not recommend machine-washing the pouch.
- If the pouch gets damp, let it air-dry at room temperature, away from direct heat, before packing your gear.
- Regularly remove fibres and debris caught in the Velcro strips so that the dividers keep holding firmly.
- Store the pouch in a dry place, away from direct sunlight.

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorama.cz
Phone	+420 252 252 098
Website	www.rotorama.com

3.2 Disposal

- The product contains no electrical or electronic parts and is not subject to the take-back of electrical equipment.
- Dispose of a worn-out pouch with mixed municipal waste, or take it to a textile collection point or a recycling centre in accordance with your local rules.
- Sort the packaging by material into the appropriate recycling containers.

4. Warranty and rights arising from defective performance

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.