EMAX Neck Strap

Neck strap for RC transmitters
User manual



Read this manual before first use and keep it for future reference.

www.rotorama.com

Contents

1. Product description

1.1 Purpose

1.2 Technical data and package contents

2. Use

2.1 Parts

2.2 Attaching the transmitter

2.3 Adjusting the length

2.4 Quick release of the transmitter

2.5 Safety, care and storage

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

3.2 Disposal

4. Warranty and rights arising from defective performance

1. Product description

1.1 Purpose

The EMAX Neck Strap is a neck strap for an RC transmitter (radio controller). The transmitter hangs on the strap in front of your body, so its weight is not carried by your hands and wrists alone, and your hands stay free, for example when preparing the drone, changing the battery or putting on FPV goggles.

The strap attaches to the transmitter with a metal snap hook. Its length is adjustable, and a plastic quick-release buckle lets you detach and reattach the transmitter quickly without taking the strap off your neck.



EMAX Neck Strap – complete strap (left) and strap with the buckle released (right)

1.2 Technical data and package contents

Manufacturer	EMAX
Product designation	EMAX Neck Strap (Remote Transmitter Strap)
Manufacturer code	0107999001
Attachment to transmitter	metal snap hook
Release	plastic quick-release buckle
Length	adjustable
Package contents	1× transmitter strap
Not included	RC transmitter (radio controller) or any other accessories

※ The manufacturer does not state the exact dimensions, weight or material composition.

2. Use

2.1 Parts



Parts of the strap

① Neck section of the strap

② Sliding plastic adjusters

③ Male part of the quick-release buckle

④ Female part of the quick-release buckle (on the short section of the strap)

⑤ Metal snap hook for attaching the transmitter

2.2 Attaching the transmitter

- Make sure your transmitter has an eyelet or mount intended for a strap. If it does not, do not attach the strap to other parts of the transmitter (antenna, sticks, switches).
- Open the snap hook ⑤, hook it into the transmitter's eyelet and release it. Check that the snap hook has closed completely.
- If the buckle is released, connect it: push part ③ into part ④ until it clicks.
- Put the neck section ① over your head and let the transmitter hang freely in front of your body.

2.3 Adjusting the length

Adjust the length of the strap so that the transmitter hangs at a height at which you can hold it comfortably with your hands in a natural position and your elbows close to your body. Use the sliding plastic adjusters ② to do this. Adjust the length without the transmitter attached, and after adjusting, check that the adjusters do not slide on their own.

2.4 Quick release of the transmitter

Press the side latches of the buckle and pull part ③ out of part ④. The transmitter remains attached to the short section of the strap with the snap hook ⑤, and the neck section ① stays around your neck. To reattach, push part ③ into part ④ until it clicks, and pull to check that the buckle holds.

2.5 Safety, care and storage

Risk of strangulation! Keep the strap out of reach of small children and do not wear it near rotating propellers, machinery or other equipment that could catch it.

- The strap is intended only for carrying an RC transmitter. Do not use it to hang other objects, as a tow rope or as a fall-protection device.
- Before each use, check the seams, band, buckle and snap hook. Do not continue to use a damaged strap (torn band, cracked buckle, bent snap hook or one that does not close).
- Do not rely on the strap to catch a falling transmitter – always hold the transmitter in your hands while flying.
- Wipe a dirty strap with a damp cloth, if necessary with a small amount of mild detergent. Do not use solvents, and let the strap dry naturally.
- Store it in a dry place away from direct sunlight.

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorama.cz
Phone	+420 252 252 098
Website	www.rotorama.com

3.2 Disposal

- The product **is not electrical equipment** and contains no batteries; the take-back scheme for electrical equipment does not apply to it.
- The strap consists of a textile band, plastic buckles and sliders, and a metal snap hook. At the end of its service life, dispose of it in accordance with the waste management rules applicable where you use the product (in the Czech Republic according to the system of the municipality where the waste is generated).
- The metal snap hook can be detached before disposal and taken to metal collection.
- Sort the product packaging according to the type of material.

4. Warranty and rights arising from defective performance

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.