Battery Strap 20x250

Silicone battery strap
User Manual



Read this manual before first use and keep it for future reference.

www.rotorama.com

Contents

1. Product description

1.1 Purpose

1.2 Specifications and package contents

2. Use

2.1 Attaching the battery

2.2 Inspection and care

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

3.2 Disposal

4. Warranty and rights arising from defective performance

1. Product description

1.1 Purpose

The Rotorama Battery Strap is a strap for securing the flight battery to the frame of a drone (copter). The strap is passed around the battery and through the frame, tightened through the metal buckle and fastened with the hook-and-loop closure. The battery thus stays firmly in place even during aggressive manoeuvres.

One side of the strap is coated with a silicone anti-slip layer, which holds the battery in place better and prevents it from shifting. The metal buckle increases the durability of the strap when it is tightened repeatedly.



Parts of the strap

① Metal buckle

② Silicone anti-slip layer

③ Hook-and-loop closure

1.2 Specifications and package contents

Product designation	Rotorama Battery Strap 20x250
Width	20 mm
Length	250 mm
Weight	4.7 g
Fastening	metal buckle and hook-and-loop closure
Surface	silicone anti-slip layer on one side
Package contents	1× strap

Not included: battery, drone or frame.

2. Use

2.1 Attaching the battery

1. Thread the strap through the strap slots in the drone frame. The silicone layer ② must face the battery.
2. Place the battery on the frame and position it so that the centre of gravity of the drone is correct.
3. Lead the free end of the strap over the battery and pass it through the metal buckle ①.
4. Pull the strap tight, fold the end back and press the hook-and-loop closure ③ down along its whole length.
5. Check that the battery does not shift in the strap and that neither the strap nor its free end interferes with the propellers, camera or antennas.

- The battery leads (power lead and balance connector) must not be pinched under the strap.
- Do not tighten the strap so much that it deforms the battery. Do not use a damaged or swollen battery.

2.2 Inspection and care

- Before every flight, check that the strap is not torn or cut, that the hook-and-loop closure holds well and that the buckle is not deformed.
- Sharp edges of the strap slots in a carbon frame can gradually cut into the strap. Replace a worn strap in good time.
- Keep the silicone layer clean – dust, sand and grease reduce its anti-slip effect. Wipe it with a damp cloth and let it dry.
- Remove grass, hair and dirt from the hook-and-loop closure, as they reduce its grip.

A battery that comes loose in flight can cause the drone to crash. Do not use a damaged strap.

3. Information for the EU and Czech Market

We sell the product in the Czech Republic, therefore Chapters 3 and 4 are based on Czech law. However, the law of the country in which the product is used is decisive.

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorama.cz
Phone	+420 252 252 098
Website	www.rotorama.com

3.2 Disposal

- The product is not electrical equipment and does not contain a battery.
- At the end of its service life, dispose of it in accordance with the waste management rules applicable where you use the product.
- Put the packaging into separated waste collection according to the type of material.

4. Warranty and rights arising from defective performance

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.