SEQURE PD65W

65 W USB mains power adapter
USB-C PD 65 W + USB-A QC3.0 18 W



Read the safety instructions in chapter 3 before first use. Keep this manual for future reference.

www.rotorama.com

Contents

1. Product description

1.1 Intended use

1.2 Technical data and package contents

1.3 Outputs and dimensions

2. Use

2.1 Connecting to the mains

2.2 Choosing the output

2.3 Powering a soldering iron and other USB-C PD devices

2.4 After use

3. Safety, maintenance and troubleshooting

3.1 Safety instructions

3.2 Maintenance and storage

3.3 Troubleshooting

4. Information for the EU and Czech Market

4.1 Importer and responsible person in the EU

4.2 Product conformity

4.3 Disposal of electrical equipment

5. Warranty and rights arising from defective performance

1. Product description

1.1 Intended use

The **SEQURE PD65W** is a USB mains power adapter with two outputs: **USB-C** with the **USB Power Delivery (PD)** protocol and up to **65 W**, and **USB-A** with the **Quick Charge 3.0 (QC3.0)** protocol and up to **18 W**. It plugs directly into a 100–240 V mains socket.

The USB-C output is suitable for powering devices with a USB-C PD input, such as a soldering iron or a battery charger. The USB-A output can be used to charge a phone or an action camera. A braided USB-C – USB-C cable rated for 100 W / 5 A is included.



SEQURE PD65W power adapter (EU plug version) and the supplied USB-C – USB-C cable

1.2 Technical data and package contents

Manufacturer	SEQURE
Product designation	PD65W
Input voltage	100–240 V ~ 50/60 Hz
USB-C output (PD)	5 V / 3 A, 9 V / 3 A, 12 V / 3 A, 15 V / 3 A, 20 V / 3.25 A (max. 65 W)
USB-A output (QC3.0)	5 V / 3 A, 9 V / 2 A, 12 V / 1.5 A (max. 18 W)
Maximum total power	65 W
Adapter dimensions	65 × 61 × 30 mm
Adapter weight	approx. 100 g
Cable	USB-C – USB-C, length 1 m, max. 100 W / 5 A, nylon braid, transparent connectors with indicator light
Plug versions	EU, UK, US, AU

▶ **Package contents**

- 1× PD65W mains power adapter
- 1× USB-C – USB-C cable 100 W / 5 A, 1 m

▶ **Not included**

- USB-A cable for the QC3.0 output
- powered devices (soldering iron, charger, phone, etc.)
- plug travel adapter

1.3 Outputs and dimensions

Both outputs are located side by side on one side of the adapter and are labelled: USB-C with **PD**, USB-A with **QC3.0**.



Adapter outputs: top USB-C (PD, up to 65 W), bottom USB-A (QC3.0, up to 18 W)



Adapter dimensions

2. Use

2.1 Connecting to the mains

Plug the adapter directly into a 100–240 V ~ 50/60 Hz mains socket. The **EU** plug version is intended for sockets in the Czech Republic and in most countries of continental Europe. The UK, US and AU versions are intended for sockets in the respective countries.

- Insert the plug fully into the socket, holding the adapter by its body, not by the cable.
- Do not use damaged, loose or overloaded sockets and extension leads.
- Do not use the adapter with a plug that does not fit the socket, and do not modify the plug in any way.

2.2 Choosing the output

Output	Use
USB-C (PD)	Devices with a USB-C input supporting USB Power Delivery – soldering iron, battery charger. Up to 65 W (20 V / 3.25 A).
USB-A (QC3.0)	Phone, action camera and other devices powered from USB-A. Up to 18 W; devices without QC3.0 support are charged at 5 V.

The output voltage is set automatically – the adapter negotiates with the connected device using the PD or QC3.0 protocol. A device never receives a higher voltage than it supports itself.

※ The total output power of both outputs is max. 65 W. If the device on the USB-C output needs the full 65 W, do not connect anything to the USB-A output at the same time.

2.3 Powering a soldering iron and other USB-C PD devices


① Check in the manual of the powered device what voltage and power it requires. The adapter supplies max. 20 V / 3.25 A (65 W).

② Connect the USB-C output of the adapter to the input of the device using the supplied USB-C – USB-C cable.

③ Plug the adapter into the socket and switch the device on according to its manual.

④ When you have finished, switch the device off, disconnect the cable and unplug the adapter from the socket.

The supplied cable is rated for 100 W / 5 A, so it does not limit the adapter's output in any way. A cable with a lower current rating may prevent full power from being reached – the device is then powered or charged more slowly.



USB-C – USB-C cable, 1 m, 100 W / 5 A

2.4 After use

- Disconnect the powered devices and unplug the adapter from the socket when not in use.
- When unplugging, hold the adapter by its body; do not pull on the cable.
- Do not bend the cable sharply at the connectors and do not wind it tightly around the adapter.

3. Safety, maintenance and troubleshooting

Information on legal regulations in this manual describes the situation in the Czech Republic. If you use the product in another country, the law of the country in which the product is operated is decisive.

3.1 Safety instructions

- The adapter is intended for use **in dry indoor areas** only. Protect it from water, moisture, condensation, dust and direct sunlight.
- Do not use the adapter or the cable if they are visibly damaged (cracked housing, bent pins, damaged insulation or connector), if they have got wet, or if they have been dropped and do not work properly.
- Do not open or repair the adapter. Dangerous mains voltage is present inside.
- The adapter heats up during operation. Do not cover it and do not use it on a soft surface, in bed or near flammable materials and heat sources.
- Do not touch the adapter or the plug with wet hands.
- Keep the adapter and the cable out of the reach of children. The product is not a toy.
- Only power devices that are designed to be powered from USB and whose requirements match the output ratings of the adapter.
- Charge devices with a battery under supervision and on a non-flammable surface; follow the manual of the device being charged.
- If you notice a smell, smoke, unusual noise or excessive heat, unplug the adapter immediately and do not use it any further.

3.2 Maintenance and storage

- Unplug the adapter from the socket before cleaning. Wipe it with a dry soft cloth; do not use water, solvents or cleaning sprays.
- Keep the connectors clean and dry; remove dirt from the USB ports with dry air.
- Store in a dry place at room temperature, out of the reach of children.

3.3 Troubleshooting

Problem	Possible cause and solution
The device is not powered or not charging	Check that the socket is live and the adapter is fully inserted. Check that the cable connectors are pushed fully home. Try another cable or the other output.
The device charges slowly	The device on USB-A does not support QC3.0, or both outputs are loaded at the same time. The cable used may not be rated for the required current – use the supplied cable.
The soldering iron does not reach full power	Check that the soldering iron supports USB PD and a 65 W power source. Disconnect any device from the USB-A output and use the supplied 100 W / 5 A cable.
The adapter is warm	Slight warming under higher load is normal. Ensure free airflow around the adapter. If the adapter is hot to the touch or smells, unplug it immediately and do not use it any further.

4. Information for the EU and Czech Market

4.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorama.cz
Phone	+420 252 252 098
Website	www.rotorama.com

4.2 Product conformity

CE

- The product bears the **CE** marking and complies with the requirements of the applicable European Union harmonisation legislation.
- A copy of the **EU Declaration of Conformity** is available from the importer at the address stated above or at the e-mail address info@rotorama.cz.
- **Product identification:** SEQURE PD65W – 65 W USB mains power adapter. Variant code by plug type: EU **DYTTC65WOPD**, UK **DYTTC65WYPD**, US **DYTTC65WMPD**, AU **DYTTC65WAPD**. The type designation is given on the product or its packaging.

4.3 Disposal of electrical equipment



- The crossed-out wheeled bin symbol on the product, its packaging or in the documentation means that at the end of its service life the product **must not be disposed of together with mixed municipal waste**.
- Hand it over at a take-back point for electrical equipment – at a collection yard, at a take-back point of a collective system, or at the retailer when purchasing a new equivalent product. Take-back is free of charge for the end user.
- The obligations under Act No. 542/2020 Coll., on end-of-life products, are fulfilled by the importer through a collective take-back system.
- Proper disposal helps prevent negative impacts on the environment and human health and contributes to the reuse of secondary raw materials.

Through its contractual partner **ASEKOL a.s.**, the company ensures the take-back of waste electrical equipment from households and the separate collection of waste electrical equipment, batteries and accumulators in accordance with the applicable legislation. The customer is entitled to hand over old electrical equipment or a battery or accumulator at any collection point of the above contractual partner. The addresses of these take-back points are listed at www.asekol.cz, www.ecobat.cz and also https://visoh2.mzp.cz/RegistrMistZO/RegistrMistZOPublic/MapaMistZpetOdberu.

5. Warranty and rights arising from defective performance

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 4.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.