



SPECIFICATIONS

- Size: 32.8*25.5*12.8mm
- Weight: 13.3g
- Power Supply: DC 3.0~12.0V
- Current: 35mA (5V)
- Telemetry Protocol: CRSF

INCLUDES

- 1x RadioMaster ERS-GPS
- 1x CRSF Wire

COMPATIBLE RECEIVERS

ER6 / ER8 / ER8G / ER8GV 2.4GHz ELRS PWM Receivers

SETUP

1. Discover New Sensors
2. Select Widget
3. Choose "VALUE"
4. Source = (Choose One of the following:)
 - [GPS] GPS Full Data
 - [GSpd] GPS Ground Speed
 - [GSpd+] GPS Max Ground Speed
 - [GSpd-] GPS Minimum Ground Speed

GPS LED

Flashing: Searching for GPS

Solid ON: Four or more satellites are acquired

INTRODUCTION

The **ERS-GPS** Telemetry Sensor is a specialized GPS unit designed by Radiomaster for the ER series ExpressLRS PWM receivers. This plug-and-play sensor integrates with the receiver via the CRSF interface. Equipped with two modes: Mode one to provide accurate GPS data and Mode two to provide accurate ground speed. Mode one is ideal capturing position and altitude logs when used with our ER series receivers with built-in barometers. Mode two is ideal for measuring speed in airplanes, jets, boats, or cars. Additionally, the ERS-GPS features a pass-through function that allows for easy future expansion of telemetry sensors through a daisy-chain arrangement.

FEATURES

- GPS Data mode and GPS Ground speed mode: Log your GPS position or track your speed in real-time and quickly access peak performance stats.
- Future-Ready Pass-Through: The ERS GPS comes equipped with an in-and-out pass-through port, allowing you to daisy-chain additional sensors in the future – no need to swap out hardware as your needs evolve.
- Seamless ExpressLRS Integration: Designed to work effortlessly with compatible ER series ExpressLRS receivers.

MODE INDICATOR

Blue: 10Hz Ground speed data. (speed runs / top speed recording)
Red: GPS position data. (GPS position logging)

PRESS and **HOLD** button for 1 second to cycle between modes. When the green LED is solid, this means at least four satellites have been acquired.